

小米路由器 mini (r1c) 初始化设置&刷机流程


Process of Initialization settings & upgrading firmware in handset for r1c

Attention: don't cut off the power during the whole process


Step 1: connect the router to the power supply and cut the cable into the Internet port on the router (the blue one)

Step 2: connect your computer to the wifi named "xiaomi" or with a cable to the LAN port on the router

Step 3: open the browser and enter the url: www.miwifi.com



Step 4: set your router as following steps



MIWIFI

欢迎使用小米路由器



waiting several seconds

请先阅读《用户许可使用协议》后选择是否同意

处理中...

加入《用户体验改进计划》



请设置Wi-Fi名称与密码

1、 rename the wifi

Xiaomi_6E55

Wi-Fi名称

2、 set a password

Wi-Fi密码

下一步

返回

需要拨号(PPPoE) | 无线中继 | 有线中继

3、 click this button to next step



tips:if you want to set the same password as the wifi password, just make a tick in the frame before the words “与 Wi-Fi 密码相同”.

wait a minute until you see the following interface.



Now, you have finished the initialization settings. Then, go to the next step to download the version you need.


waiting a while, the step perhaps needs 5~8 minutes. If you see the next interface, it means the operation has finished.



Step 5: set the system language



设置系统语言



select English as the system language.